USER MANUAL

KWL24-110



FEATURES

- · Easy and strong to lock your bike
- PVC cover resists corrosion from water, dust and dirt to prolong the life of your lock
- 120 dB on/off alarm system

BEFORE YOU START

To use KOVIX KWL Series, check if you have the following ready:







1 x Coded Number Tag (We suggest user to keep the Coded Number Tag at a safe place for ordering key replacement in the future.)

1 x KOVIX Alarm Cable Lock KWL



1 x Allen Key



1 x CR2 lithium battery


HOW TO USE KOVIX KWL CABLE LOCK

Lock with Alarm

- 1. Insert locking pin to hole.
- 2. Insert key and turn the key clockwise to lock; you should hear ONE beep sound while locking.
- 3. The lock will emit a long beep sound after 3 seconds to confirm alarm activation.
- If movements are detected, the lock will emit 5 beeps as a warning. If movements persist, the lock will emit its 120dB alarm siren for 10 seconds.
- Auto re-alarm function The lock will re-alarm automatically if movements are detected continuously.
- 6. To unlock, insert the key and turn the key anti-clockwise.


Lock without Alarm


- 1. Insert locking pin to hole.
- Turn the key clockwise to lock; you should hear TWO beeps sound while locking.
- 3. To unlock, insert the key and turn the key anti-clockwise.



REPLACING THE BATTERY

- 1. Unlock the lock.
- 2. Using the provided Allen key, remove the screw from the electronic body. Please refer to fig.1 for clarification.
- 3. Remove the electronic alarm module from the body.
- 4. Open waterproof rubber, and insert fresh CR2 lithium battery. Please refer to fig.2 for clarification.
- 5. Reassemble parts carefully to finish, make sure that the waterproof rubber tightly covers the battery.





*The average lifespan of our CR2 lithium battery is one month to a year. Factors such as extreme temperature and high frequency of usage could reduce its lifespan.

TROUBLE SHOTTING

- 1) Alarm not working: Check if the battery is placed properly and make sure the + signs are positioned correctly. If the battery is dead, please change the battery.
- 2) Lost Key: Contact local distributor with the Coded Number Tag for key replacement.

Visit www.kovix-security.com for more product information.